




Poisson's Ratio



- For a slender bar subjected to axial loading:

$$\epsilon_x = \frac{\sigma_x}{E} \quad \sigma_y = \sigma_z = 0$$



- The elongation in the x-direction is accompanied by a contraction in the other directions. Assuming that the material is isotropic (no directional dependence),

$$\epsilon_y = \epsilon_z \neq 0$$

- Poisson's ratio is defined as

$$\nu = \left| \frac{\text{lateral strain}}{\text{axial strain}} \right| = -\frac{\epsilon_y}{\epsilon_x} = -\frac{\epsilon_z}{\epsilon_x}$$

Generalized Hooke's Law



- For an element subjected to multi-axial loading, the normal strain components resulting from the stress components may be determined from the *principle of superposition*. This requires:

- 1) strain is linearly related to stress
- 2) deformations are small

- With these restrictions:

$$\begin{aligned} \epsilon_x &= +\frac{\sigma_x}{E} - \frac{\nu\sigma_y}{E} - \frac{\nu\sigma_z}{E} \\ \epsilon_y &= -\frac{\nu\sigma_x}{E} + \frac{\sigma_y}{E} - \frac{\nu\sigma_z}{E} \\ \epsilon_z &= -\frac{\nu\sigma_x}{E} - \frac{\nu\sigma_y}{E} + \frac{\sigma_z}{E} \end{aligned}$$

Shearing Strain




Fig. 2.46

- A cubic element subjected to a shear stress will deform into a rhomboid. The corresponding *shear strain* is quantified in terms of the change in angle between the sides,

$$\tau_{xy} = f(\gamma_{xy})$$





Fig. 2.47

- A plot of shear stress vs. shear strain is similar to the previous plots of normal stress vs. normal strain except that the strength values are approximately half. For small strains,

$$\tau_{xy} = G \gamma_{xy} \quad \tau_{yz} = G \gamma_{yz} \quad \tau_{zx} = G \gamma_{zx}$$

where G is the modulus of rigidity or shear modulus.


Example 2.10



SOLUTION:

- Determine the average angular deformation or shearing strain of the block.
- Apply Hooke's law for shearing stress and strain to find the corresponding shearing stress.
- Use the definition of shearing stress to find the force P .

A rectangular block of material with modulus of rigidity $G = 90$ ksi is bonded to two rigid horizontal plates. The lower plate is fixed, while the upper plate is subjected to a horizontal force P . Knowing that the upper plate moves through 0.04 in. under the action of the force, determine a) the average shearing strain in the material, and b) the force P exerted on the plate.



- Determine the average angular deformation or shearing strain of the block.

$$\gamma_{xy} \approx \tan \gamma_{xy} = \frac{0.04 \text{ in.}}{2 \text{ in.}} \quad \gamma_{xy} = 0.020 \text{ rad}$$

- Apply Hooke's law for shearing stress and strain to find the corresponding shearing stress.


$$\tau_{xy} = G\gamma_{xy} = (90 \times 10^3 \text{ psi})(0.020 \text{ rad}) = 1800 \text{ psi}$$

- Use the definition of shearing stress to find the force P .


$$P = \tau_{xy}A = (1800 \text{ psi})(8 \text{ in.})(2.5 \text{ in.}) = 36 \times 10^3 \text{ lb}$$

$P = 36.0 \text{ kips}$

Relation Among E , ν , and G



- An axially loaded slender bar will elongate in the axial direction and contract in the transverse directions.
- An initially cubic element oriented as in top figure will deform into a rectangular parallelepiped. The axial load produces a normal strain.



- If the cubic element is oriented as in the bottom figure, it will deform into a rhombus. Axial load also results in a shear strain.
- Components of normal and shear strain are related,

$$\frac{E}{2G} = (1 + \nu)$$